

**Field Calibration Procedures
for Animal Wastewater Application Equipment**

**STATIONARY
SPRINKLER
IRRIGATION SYSTEM**



*North Carolina Cooperative
Extension Service*

North Carolina State University

Field Calibration Procedures for Animal Wastewater Application Equipment

STATIONARY SPRINKLER IRRIGATION SYSTEM

Land application equipment used on animal production farms must be field calibrated or evaluated in accordance with existing design charts and tables according to state rules that went into effect September 1, 1996. Technical Specialist certifying waste management plans after September 1, 1996, must also certify that operators have been provided calibration and adjustment guidance for all land application equipment. The rules apply to irrigation systems as well as all other types of liquid, slurry, or solid application equipment.

Information presented in manufacturers' charts are based on average operating conditions for relatively new equipment. Discharge rates and application rates change over time as equipment ages and components wear. As a result, equipment should be field calibrated regularly to ensure that application rates and uniformity are consistent with values used during the system design and given in manufacturers' specifications. Field calibration is a simple procedure involving collection and measurement of the material being applied at several locations in the application area. This publication contains step-by-step guidelines for field calibration of stationary sprinkler irrigation systems.

General Guidelines

Operating an irrigation system differently than assumed in the design will alter the application rate, uniformity of coverage, and subsequently the application uniformity. Operating with excessive pressure results in smaller droplets, greater potential for drift, and accelerates wear of the sprinkler nozzle. Pump wear tends to reduce operating pressure and flow. With continued use, nozzle wear results in an increase in the nozzle opening, which will increase the discharge rate while decreasing the wetted diameter. Clogging of nozzles or crystallization of main lines can result in increased pump pressure but reduced flow at the sprinkler. Plugged intakes will reduce operating pressure. An operating pressure below design pressure greatly reduces the coverage diameter and application uniformity. Field calibration helps ensure that nutrients from animal waste are applied uniformly and at proper rates.

The calibration of a stationary sprinkler irrigation system involves setting out collection containers, operating the system, measuring the amount of wastewater collected in each container, and then

computing the average depth of application (application volume) and application uniformity.

An in-line flow meter installed in the main irrigation line provides a good estimate of the total volume pumped from the lagoon during each irrigation cycle. The average application depth can be determined by dividing the pumped volume by the application area. The average application depth is computed from the formula:

Average application depth (inches) =

$$\frac{\text{Volume pumped (gallons)}}{27,154 \text{ (gal/ac-in)} \times \text{Application area (acres)}}$$

The average application depth is the average amount applied throughout the field. Unfortunately, sprinklers do not apply the same depth of water throughout their wetted area. Under normal operating conditions, application depth decreases towards the outer perimeter of the wetted diameter. Stationary sprinkler systems are designed to have overlap of 50 to 65 percent of the wetted sprinkler diameter to compensate for the declining application along the

outer perimeter. When operated at the design pressure, this overlap results in acceptable application uniformity.

When operated improperly, well-designed systems will not provide acceptable application uniformity. For example, if the pressure is too low, the application depth will be several times higher near the center of sprinkler and water will not be thrown as far from the sprinkler as indicated in manufacturers' charts. Even through the *average* application depth may be acceptable, some areas receive excessively high application while others receive no application at all.

When applying wastewater high in nutrients, it is important to determine the application uniformity. Collection containers distributed throughout the application area must be used to evaluate application uniformity. Many types of containers can be used to collect flow and determine the application uniformity. Standard rain gauges work best and are recommended because they already have a graduated scale from which to read the application depth.

Pans, plastic buckets, jars, or anything with a uniform opening and cross section can be used, provided the container is deep enough (at least 4 inches deep) to prevent splash and excessive evaporation, and the liquid collected can be easily transferred to a scaled container for measuring. All containers should be the same size and shape.

All collection containers should be set up at the same height relative to the height of the sprinkler nozzle (discharge elevation). Normally, the top of each container should be no more than 36 inches above the ground. Collectors should be located so that there is no interference from the crop. The crop canopy should be trimmed to preclude interference or splash into the collection container.

Calibration should be performed during periods of low evaporation. Best times are before 10 a.m. or after 4 p.m. on days with light wind (less than 5 miles per hour). On cool, cloudy days the calibration can be performed any time when wind velocity is less than 5 miles per hour.

General Guidelines for Stationary Sprinklers

Rain gauges or other collection containers should be spaced in a grid pattern fully enclosing the "effective" wetted area defined by the sprinkler spacing. The

most common spacing pattern for stationary sprinklers is a square spacing where the distance between sprinklers is the same as the spacing between laterals. The spacing between sprinklers and laterals is normally between 50 to 65 percent of the sprinkler wetted diameter specified by the manufacturer.

Collection gauges should be placed one-fourth the lateral line length from the main and no further apart than one-fourth the wetted sprinkler radius or effective sprinkler spacing. (For example, if the effective spacing is 80 feet, spacing between gauges should be no more than 20 feet).

The grid pattern and number of gauges required to complete the calibration depends on the pattern of operating the irrigation system. The size of the calibration area should be no less than the "effective" area of one sprinkler. When sprinklers are arranged in a rectangular or square pattern with proper overlap, an "effective area" receives flow from four sprinklers. Thus, a minimum of four sprinklers should be included in the calibration.

The reliability of the calibration generally improves as more sprinklers are included in the calibration area. If all sprinklers contributing flow to the calibration area are functioning correctly, it is necessary to include only the minimum number of sprinklers as described in the preceding paragraph. But, a malfunctioning sprinkler can greatly influence the calibration results. Its effect on the calibration depends on the calibration setup and number of sprinklers being calibrated, the malfunctioning sprinkler's position within the calibration area, the direction of the prevailing wind, and the nature of the malfunction. For these reasons, it is extremely important to observe the performance of every sprinkler contributing to the calibration while the calibration is being performed and to record any obvious performance irregularities. The more sprinklers that can be included in the calibration, the more representative the calibration results will be of the entire field and the less influence one malfunctioning sprinkler will have on the calibration results.

The volume (depth) collected during calibration should be read as soon as a zone or sprinkler is shut off to minimize evaporation from the rain gauge. Where a procedure must be performed more than once, (Setups 3, 4, or 5 described below) containers should be read and values recorded immediately after each different set up.

Operating patterns affect collection container

layout and calibration procedures and results. Typical patterns for stationary sprinklers include:

1. Square sprinkler spacing operated as a block (two or more adjacent laterals operating at the same time) Figure 1 or Figure 2.

The calibration area may be positioned or centered between the two laterals as shown in either Figure 1 or Figure 2. Four sprinklers contribute flow to the calibration area in the setup shown in Figure 1, while six sprinklers contribute for the setup shown in Figure 2. If all sprinklers are functioning properly, similar results would be obtained with either setup.

In case 1, with no wind effects, all four sprinklers should contribute equal flow to the calibration area (provided all sprinklers are functioning properly). If one of the four sprinklers is functioning improperly, the calibration results are not biased by its position within the calibration area.

In case 2, six sprinklers contribute flow to the calibration area, but their contribution is not equal. Sprinklers S_{13} and S_{23} contribute much more flow to the calibration area than sprinklers S_{12} , S_{14} , S_{22} , or S_{24} . (The first number refers to the lateral number and the second number refers to the sprinkler number along the lateral.) The setup shown in Figure 2 provides the advantage of more sprinklers contributing to the calibration, but the disadvantage of the results




Figure 1. Layout of collection containers for calibration of a stationary sprinkler system operated in a block design. In setup shown, four sprinklers contribute to the calibration.




Figure 2. Collection container layout for calibration of a stationary sprinkler system operated in a block design. In setup shown, six sprinklers contribute to the calibration.

potentially being biased by sprinklers S_{13} and S_{23} if they are malfunctioning.

For a square sprinkler spacing with collection gauges set at one-fourth the distance of the sprinkler

spacing, the minimum number of collection gauges required to perform the calibration is 16. Step-by-step procedures for this pattern are presented in the Case I example on page 6.

2. One lateral operating at a time with standard overlap from adjacent laterals — collection containers must be placed on each side of the lateral, Figure 3, which requires twice as many collectors (minimum 32).

A second alternative is to perform the procedure twice, once on each side of the lateral using 16 containers at a time, Figure 4. When selecting this alternative, pay attention to changes in operating conditions, such as change in wind speed or direction, that could result in variability.

In either alternative, the amounts collected must be combined to account for overlap. Step-by-step procedures for this calibration pattern are presented in the Case II example on page 8.

3. One lateral operating with no overlap between laterals — typical case when large gun-type sprinklers are operated in narrow fields, Figure 5.

Calibration procedure is similar to procedure in #2 except outer edges do not receive overlap and must be excluded from the effective area calculations. Collection gauges may be centered about one sprinkler or positioned between two adjacent sprinklers.

One of two approaches can be used to perform




Figure 3. Collection container layout for calibration of a stationary sprinkler system with one lateral operating at a time. For setup shown, both sides of lateral are calibrated in one operation.




Figure 4. Collection container layout for calibration of a stationary sprinkler system with one lateral operated at a time. For the setup shown, the procedure must be performed twice, once for lateral A, once for lateral B.

..... this calibration. A general rule in irrigation design is to assume that the width of the effective area is between 50 to 65 percent of the wetted diameter of the sprinkler (often 60 percent is used). The first




Figure 5. Collection container layout to calibrate a single lateral line with no overlap from adjacent lateral. Either setup shown (lateral A or lateral B) may be used.




Figure 6. Collection container layout to calibrate a stationary gun system when each gun is operated separately (not head to head).

edges are ignored at the onset of the calibration. Flow from all sprinklers is summed then averaged to compute the average application depth for the effective area.

For the second alternative, the entire width of the field is included in the calibration as shown in Figure 5 (Lateral B). At least 16 gauges should be set out on each side of the lateral. The calibration can be performed all at once (both sides of the lateral which requires 32 gauges) or the procedure can be performed twice, once on each side of the lateral using 16 gauges at a time.

The “non-zero” volumes collected are averaged to get a “preliminary” average application depth for the wetted area. Next, the average application depth for each row of gauges is computed (rows are assumed to be oriented parallel to the lateral). In this computation, zero values are included. Those rows whose row average is less than one-half the average from the entire wetted area are then excluded and assumed to fall outside the effective area. The effective width is the distance from the lateral line to the furthest row from the lateral that is

calibration approach accepts this design guideline that the effective width of the lateral is 60 percent of the wetted diameter of one sprinkler. Sixteen gauges are set out as shown in Figure 5 (Lateral A) (8 gauges on each side of the lateral) with all 16 gauges positioned within the effective sprinkler width. The outer

retained. Step-by-step procedures for this method are given in the Case III example on page 9.

4. Big gun sprinkler operating individually, Figure 6. Procedure must be repeated for each gun sprinkler or sprinkler position (hydrant) contributing to the effective area being calibrated. This operating situa-

tion results where one or two guns or big sprinklers are moved from hydrant to hydrant throughout the field. Since stationary big guns should not be operated “head to head.” (two or more sprinklers throwing water on the same area simultaneously); the procedure must be repeated several times.

Collection gauges may be centered about one gun

sprinkler. This setup requires that the procedure be performed three times, once while Gun 2 operates, again when Gun 3 operates, and a third time when Gun 4 operates. Collection gauges may also be centered between Gun 2 and 3 or Guns 3 and 4 as shown in Figure 6. (Actual location depends on the length of the lateral). In this setup, the procedure

CASE I. Block Pattern with 2 or more laterals operating simultaneously

(Scenarios shown in Figures 1 and 2)

1. Determine the effective sprinkler area. (Area defined by sprinkler spacing along a lateral multiplied by the spacing between laterals. (Example: 80 feet by 80 feet are typical for a solid set wastewater system). The effective sprinkler area is the **minimum** area to be included in the calibration area. Note: The calibration area can be more than the effective area of one sprinkler.
2. Determine the necessary spacing between collection gauges (1/4 the sprinkler spacing). For an effective sprinkler spacing of 80 feet, the rain gauge spacing should not exceed 20 feet. (80 ft / 4 = 20 ft). Gauges closest to the sprinklers should be placed a distance of 1/2 the gauge spacing from the sprinkler. For a gauge spacing of 20 feet, the first row of gauges should be 10 feet from the lateral line or sprinklers.
3. Determine the number of gauges required. (Minimum number is 16.)

$$\text{Number of gauges} = \frac{\text{Calibration area (ft}^2\text{)}}{\text{Gauge area (ft}^2\text{)}}$$

Example: Calibration area = 80 ft x 80 ft = 6400 ft²

Gauge area = 20 ft x 20 ft = 400 ft²

$$\text{Number of gauges} = \frac{6400 \text{ ft}^2}{400 \text{ ft}^2} = 16 \text{ gauges}$$

4. Set out gauges in a rectangular pattern as shown in Figure 1 or 2, equally spaced at the distance determined in item 2 (20 feet) within the calibration area.
5. Operate the system for normal operating time for a full cycle. Record the time of operation (duration in hours).
6. Immediately record the amounts collected in each gauge. (Refer to Worksheet No. 1 for an example.)
7. Add the amounts in #6 and divide by the number of gauges. This is the average application depth (inches).

$$\text{Average application depth} = \frac{\text{Sum of amounts collected in all gauges}}{\text{Number of gauges}}$$

CASE I. (continued)

8. Calculate the deviation depth for each gauge. The deviation depth is the difference between each individual gauge value and the average value of all gauges (#7). Record the absolute value of each deviation depth (absolute value means the sign of the number (negative sign) is dropped and all values are treated as positive). The symbol for absolute value is a straight thin line. For example, |2| means treat the number 2 as an absolute value. It does not mean the number 121. Because this symbol can lead to misunderstandings, it is not used with numbers in the worksheets at the end of this publication. The symbol is used in formulas in the text.

$$\text{Deviation depth} = |\text{Depth collected in gauge } i - \text{average application depth}|$$

"i" refers to the gauge number

9. Add amounts in #8 to get "sum of the deviations" from the average depth and divide by the number of gauges to get the average deviation.

$$\text{Average deviation depth} = \frac{\text{Sum of deviations (add amounts computed in \#8)}}{\text{Number of gauges}}$$

10. The precipitation rate (inches/hour) is computed by dividing the average application depth (inch) by the application time (hours)

$$\text{Precipitation rate} = \frac{\text{Average application depth (inch)}}{\text{Application time (hours)}}$$

11. Determine the application uniformity. The application uniformity is often computed using the mathematical formula referred to as the Christiansen Uniformity Coefficient. It is computed as follows:

$$U_c = \frac{\text{Average depth (\#7)} - \text{average deviation (\#9)}}{\text{Average depth (\#7)}} \times 100$$

12. Interpret the calibration results. The higher the index value, the more uniform the application. An index of 100 would mean that the uniformity is perfect — that the exact same amount was collected in every gauge.

An application uniformity greater than 75 is excellent for stationary sprinklers.

Application uniformity between 50 to 75 is in the "good" range and is acceptable for wastewater application.

Generally, an application uniformity below 50 is not acceptable for wastewater irrigation with stationary sprinklers. If the computed U_c is less than 50, system adjustments are required. Contact your irrigation dealer or Certified Technical Specialist for assistance.

CASE II. Single lateral operated at one time but receives overlap from adjacent laterals.

(Scenarios shown in Figures 3 and 4)

1. Determine the effective sprinkler area. (Lateral spacing times sprinkler spacing along lateral).
2. Determine the necessary spacing between collection gauges. (Lateral spacing divided by 4). Gauges closest to the sprinklers should be placed a distance of one-half the gauge spacing from the sprinkler.
3. Determine the number of gauges required.
 - Minimum number is 32 to perform the procedure in one setup, Figure 3; or
 - One side of lateral calibrated at a time requires 16 gauges, procedure performed twice, first operating Lateral A (Figure 4) then repeated without moving gauges and operating Lateral B.
4. The amount collected on one side of the lateral must be added to the amount collected from respective positions on the other side of the lateral. This is necessary to account for overlap from adjacent laterals. Therefore, collection gauges should be labeled to indicate their respective positions, such as left or right of the lateral.
5. Set out gauges in a rectangular pattern as shown in Figures 3 or 4, equally spaced at the distance determined in item 2.
6. Operate the system for normal operating time for a full cycle. Record the time of operation (duration in hours).
7. Immediately record the amounts collected in each gauge. (Refer to Work Sheet No. 2 for an example). If only one side of the lateral is calibrated at a time, after recording collection amounts, empty and move the collection containers to the other side and repeat steps 5 through 7 for exactly the same time duration as recorded in item 6.
8. Collection amounts from pairs of cans should be added to simulate overlap. Contents should be combined from one side of the lateral to the other side as shown in Figure 3. Referring to Figure 3, container L1 is combined to R1, L2 to R2, L3 to R3, L4 to R4, L5 to R5, and so on.
9. Add the amounts from all containers and divide by the number of gauges on one side of the lateral. This is the average application depth (inches).

$$\text{Average application depth} = \frac{\text{Sum of amounts collected in all gauges}}{\text{Number of gauges on one side of lateral}}$$

10. Calculate the deviation depth for each gauge. The deviation depth is the difference between combined depth for each position (values computed in #8) and the average application depth (#9). Record the absolute value of each deviation depth. Absolute value means the sign of the number (negative sign) is dropped and all values are treated as positive. The symbol for absolute value is a thin straight line.

$$\text{Deviation depth} = |\text{Depth collected at position } i - \text{average application depth}|$$

"i" refers to the gauge position within the effective calibration area

11. Add amounts in #10 to get "sum of the deviations" from the average depth and divide by the number of gauges (number of gauges on one side of lateral) to get the average deviation depth.

$$\text{Average deviation depth} = \frac{\text{Sum of deviations (add amounts computed in #10)}}{\text{Number of gauges on one side of lateral}}$$

Number of gauges on one side of lateral

CASE II. (continued)

12. Determine the application uniformity. The application uniformity is often computed using the mathematical formula referred to as the Christiansen Uniformity Coefficient. It is computed as follows:

$$U_c = \frac{\text{Average depth (\#9)} - \text{average deviation (\#11)}}{\text{Average depth (\#9)}} \times 100$$

13. Interpret the calibration results. The higher the index value, the more uniform the application. An index of 100 would mean that the uniformity is perfect — the exact amount was collected in every gauge.

An application uniformity greater than 75 is excellent for stationary sprinklers.

Application uniformity between 50 to 75 is in the “good” range and is acceptable for wastewater application.

Generally, an application uniformity below 50 is not acceptable for wastewater irrigation. If the computed U_c is less than 50, system adjustments are required. Contact your irrigation dealer or Certified Technical Specialist for assistance.

CASE III. Single Lateral or Gun Sprinkler without overlap from adjacent laterals.

(Scenarios shown in Figures 5 or 6)

1. Determine the wetted diameter of a sprinkler or field width.
2. Determine the necessary spacing between collection gauges. The spacing in the direction along the lateral should be one-fourth the effective sprinkler spacing. The gauge spacing perpendicular to the lateral should be 1/8 the wetted diameter or width of the field.

$$\text{Spacing between collection gauges parallel to lateral} = \frac{\text{Effective sprinkler spacing in feet}}{4}$$

$$\text{Spacing between collection gauges perpendicular to lateral} = \frac{\text{Sprinkler wetted diameter in feet}}{8}$$

3. Determine the number of gauges required.
 - Minimum number is 32 to perform the procedure in one setup (both sides of lateral at the same time).
 - One side of lateral calibrated at a time requires 16 gauges, procedure performed twice, once on each side of the lateral.
4. Set out gauges in a rectangular grid pattern as shown in Figure 5, spaced at the distances determined in item 2. Be sure to label gauges by rows (rows should be oriented parallel to and outward from the lateral line). The first row of gauges should be located 1/2 the gauge spacing from the lateral.
5. Operate the system for normal operating time for a full cycle. Record the time of operation (duration in hours).

CASE III. (continued)

6. Immediately record the amounts collected in each gauge. (Refer to Work Sheet No. 3 for an example). If only one side of the lateral is calibrated at a time, after recording collection amounts, empty and move the collection containers to the other side and repeat steps 4 through 6 for exactly the same time duration as recorded in item 5.
7. Add the "non-zero" amounts collected and divide by the number of gauges with a non-zero amount. This is the "preliminary" average application depth (inches) within the "wetted" calibration area.

$$\text{Average application depth} = \frac{\text{Sum of non-zero amounts collected}}{\text{Number of non-zero gauges}}$$

8. Determine the average application depth by rows. Include zero catches in the row computations.

$$\text{Average row application depth} = \frac{\text{Sum of collection amounts from all gauges on the row}}{\text{Number of row gauges}}$$

9. Identify and delete those rows whose average application depth (#8) is less than one-half the preliminary average application depth (#7).
10. Determine the effective application width. The boundary is defined as the distance from the lateral to the last row furthest from the lateral that is retained.
11. Determine the average application depth within the effective area. Add amounts from all gauges in rows within the effective width (Rows retained in #9 and #10).

$$\text{Corrected average application depth} = \frac{\text{Sum of amounts collected in rows within effective width}}{\text{Number of gauges within the effective width}}$$

12. Calculate the deviation depth for each gauge. The deviation depth is the difference collected in each usable gauge and the average application depth (#11). Record the absolute value of each deviation depth. Absolute value means the sign of the number (negative sign) is dropped and all values are treated as positive. The symbol for absolute value is a thin straight line.

$$\text{Deviation depth} = |\text{Depth collected at position } i - \text{average application depth (\#11)}|$$

"i" refers to the gauge position within the effective calibration area

13. Add amounts in #12 to get "sum of the deviations" from the average depth and divide by the number of gauges.

$$\text{Average deviation depth} = \frac{\text{Sum of deviations (add amounts computed in \#12)}}{\text{Number of gauges within the effective width}}$$

14. Determine the application uniformity. The application uniformity is often computed using the mathematical formula referred to as the Christiansen Uniformity Coefficient. It is computed as follows:

$$U_c = \frac{\text{Average application depth (\#11)} - \text{average deviation (\#14)}}{\text{Average depth (\#11)}} \times 100$$

CASE III. (continued)

15. Interpret the calibration results. The higher the index value, the more uniform the application. An index of 100 would mean that the uniformity is perfect — the exact amount was collected in every gauge.

An application uniformity greater than 75 is excellent for stationary sprinklers.

Application uniformity between 50 to 75 is in the “good” range and is acceptable for wastewater application.

Generally, an application uniformity below 50 is not acceptable for wastewater irrigation. If the computed U_c is less than 50, system adjustments are required. Contact your irrigation dealer or Certified Technical Specialist for assistance.

WORK SHEET 1. Example calibration data for a stationary sprinkler system operated in a block pattern. (Setup as shown in Figure 1)

- a. Effective sprinkler area: 80 ft by 80 ft = 6400 ft²
- b. Spacing between collection containers (spacing 80 (ft)/4) = 20 ft
- c.
$$\text{Number of gauges} = \frac{\text{calibration area (ft}^2\text{)}}{\text{effective gauge area (ft}^2\text{)}} = \frac{6400 \text{ ft}^2}{20 \text{ ft} \times 20 \text{ ft}} = 16$$
- d. Start of Irrigation event 7:15 a.m.
- e. End of Irrigation event 9:30 a.m.
- f. Duration (e-d) 2.25 hours
- g. Operate the system and collect data

Gauge No.	Volume Collected (inches)	Deviation from Average* (absolute value)	Gauge No.	Volume Collected (inches)	Deviation from Average* (absolute value)
1	.57	.005	9	.51	.065
2	.69	.115	10	.26	.315
3	.83	.255	11	.36	.215
4	.65	.075	12	.52	.055
5	.61	.035	13	.79	.215
6	.38	.195	14	.65	.075
7	.27	.305	15	.61	.035
8	.64	.065	16	.86	.285

* Record the absolute value of each deviation, so all values are treated as positive.

WORK SHEET 1. (*continued*)

- h. Sum of volume collected in all catches 9.20 inches
- i. Average application depth (h/c) (9.2/16) .576 inches
- j. Precipitation rate = $\frac{0.576 \text{ inches}}{(2.25 \text{ hour})} = 0.26 \text{ inches/hour}$
- k. Sum of all deviations from the average depth 2.31
- l. Average deviation from average depth (k/c) 0.144
- m. Uniformity coefficient

$$U_c = \frac{0.576 - 0.144}{0.576} \times 100 = 74.9$$

- n. Interpret Results. Uniformity coefficient is in the good range, so no adjustments are necessary

WORK SHEET 2. Example calibration data for a stationary sprinkler system, one lateral operated at a time. (Setup as shown in Figure 3.)

- a. Effective sprinkler area: 80 ft by 80 ft = 6400 ft²
- b. Spacing between collection containers (spacing 80 (ft) / 4) = 20 ft
- c. Number of gauges = $\frac{\text{Calibration area (ft}^2\text{)}}{\text{Effective gauge area (ft}^2\text{)}} = \frac{2 \times 80 \text{ ft} \times 80 \text{ ft}}{20 \text{ ft} \times 20 \text{ ft}} = 32$
- d. Start of Irrigation event 7:15 a.m.
- e. End of Irrigation event 9:30 a.m.
- f. Duration (e-d) 2.25 hours
- g. Operate the system, collect data, and record on the worksheet on page 13, opposite.
- h. Sum of all catches 10.91 inches
- i. Average application depth (h/16) 0.682 inches
- j. Sum of all deviations from the average depth 1.866
- k. Average deviation from average depth 0.117
- l. Uniformity coefficient

$$U_c = \frac{0.682 - 0.117}{0.682} \times 100 = 82.8$$

- m. Interpret Results. Uniformity coefficient is in the excellent range for a stationary sprinkler system. No adjustment necessary.

WORK SHEET 2. (continued)

Gauge No.	Volume Collected (inches)	Overlap Adjustment	Deviation from Average*
L1	.00	.67 (L1 + R1)	.012 (L1+R1) - i
L2	.15	.64 (L2 + R2)	.042 (L2+R2) - i
L3	.38	.72 (L3 + R3)	.038 (etc)
L4	.71	.71 (L4 + R4)	.028
L5	.02	.86 (L5 + R5)	.178
L6	.20	.79 (etc)	.108
L7	.43	.53	.152
L8	.78	.80	.118
L9	.04	.82	.138
L10	.33	.94	.258
L11	.51	.74	.058
L12	.69	.69	.008
L13	.00	.51	.172
L14	.11	.44	.242
L15	.37	.47	.212
L16	.58	.58	.102

*Record the absolute value; treat all values as positive.

R1	.67
R2	.49
R3	.34
R4	.00
R5	.84
R6	.59
R7	.10
R8	.02
R9	.78
R10	.61
R11	.23
R12	.00
R13	.51
R14	.33
R15	.10
R16	.00

would be performed twice since only two guns or gun locations contribute to the calibration.
WORK SHEET 3. Example calibration data for a stationary sprinkler system, one lateral operated at a time, no overlap from adjacent laterals. (Setup as shown in Figure 5, lateral B.)

- a. Determine the wetted diameter of a sprinkler.
From manufacturers literature, wetted diameter is 160 feet, sprinkler spacing along lateral is 100 feet.

- b. Determine the necessary spacing between collection gauges.

$$\text{parallel to lateral} = \frac{\text{sprinkler spacing}}{4} = \frac{100 \text{ [feet]}}{4} = 25 \text{ feet}$$

$$\text{perpendicular to lateral} = \frac{\text{sprinkler wetted diameter}}{8} = \frac{160 \text{ feet}}{8} = 20 \text{ feet}$$

- c. Determine the number of gauges required.

Will calibrate both sides of lateral at one time so need 32 collection gauges

First row of gauges should be located a distance of 1/2 the gauge spacing from the lateral line. i.e., if the gauge spacing is 20 feet, first row of gauges should be 10 feet from the lateral.

- d. Start of irrigation event 7:15 a.m.

- e. End of irrigation event 9:30 a.m.

- f. Duration (e-d) 2.25 hours

- g. Operate the system and collect data

- h. Add the non zero amounts collected and divide by the number of gauges with a non-zero amount. This is the average application depth (inches) within the "wetted" calibration area.

Sum of non zero catches in column 3 = 12.59 inches

Number of gauges with non-zero catch = 28 gauges

$$\text{Average catch all non-zero gauges} = \frac{12.59 \text{ inches}}{28 \text{ gauges}} = 0.45 \text{ inches}$$

- i. Determine the average application depth by rows. Include zero catches in the row computations.
Row averages are shown in column 4.

- j. Identify and delete those rows whose average application depth (#i) is less than one-half the average application depth (#h).

Application depth of Row L4 is 0.05 inches and Row R4 is 0.04 inches so discard row 4 values on both sides (left and right) of lateral.

- k. Determine the effective application width.

Row 3 is last usable row and is located 50 feet from lateral (column 3). Therefore, effective width is 50 feet on each side of lateral or 100 feet total.

WORK SHEET 3. (continued)

Gauge No.	Distance from Lateral	Volume Collected (inches)	Row Average	Usable Values	Deviation from Average
L11	10	.77		.77	.260
L12	10	.69		.69	.180
L13	10	.83		.83	.320
L14	10	.65	.74	.65	.140
L21	30	.61		.61	.100
L22	30	.57		.57	.060
L23	30	.48		.48	.030
L24	30	.44	.53	.44	.070
L31	50	.31		.31	.200
L32	50	.22		.22	.290
L33	50	.18		.18	.330
L34	50	.29	.25	.29	.220
L41	70	.12			
L42	70	.0			
L43	70	.0			
L44	70	.08	.05 (discard)		
R11	10	.67		.67	.160
R12	10	.79		.79	.280
R13	10	.81		.81	.300
R14	10	.77	.76	.77	.260
R21	30	.59		.59	.080
R22	30	.51		.51	.000
R23	30	.62		.62	.110
R24	30	.5	.56	.50	.010
R31	50	.37		.37	.140
R32	50	.17		.17	.340
R33	50	.15		.15	.360
R34	50	.24	.23	.24	.270
R41	70	.07			
R42	70	.0			
R43	70	.0			
R44	70	.09	.04 (discard)		

WORK SHEET 3. (continued)

- l.** Determine the average application depth within the effective area. Add amounts from all gauges in rows within the effective width (Rows 1, 2, and 3 on both sides of lateral.)

Usable values are shown in column 5 sum of amounts collected in rows within effective width (sum of column 5) = 12.23 inches

$$\text{Average application depth} = \frac{12.23 \text{ inches}}{24 \text{ gauges}} = 0.51 \text{ inches}$$

- m.** Calculate the deviation depth for each gauge. Values shown in column 6.

$$\text{Deviation depth} = |\text{Depth collected at position } i - \text{average application depth } (\#l)|$$

i refers to the gauge position within the effective calibration area

- n.** Sum of deviations (sum of values in column 6) = 4.511 inches

$$\text{Average deviation depth} = \frac{4.511 \text{ inches}}{24 \text{ gauges}} = 0.188 \text{ inches}$$

- o.** Determine the application uniformity.

$$U_c = \frac{0.51 \text{ inches } (\#l) - 0.188 \text{ inches } (\#n)}{0.51 \text{ inches } (\#l)} \times 100 = 63.1$$

- p.** Interpret the calibration results. An index value of 63 percent is acceptable for a stationary sprinkler system. No adjustments are needed.

Irrigation System Calibration Data Sheet for Stationary Sprinkler

Date _____ Farm _____ Tract No. _____

- a. Effective sprinkler area: Lateral spacing _____ ft by spacing along lateral _____ ft = _____ ft²
 Sprinkler: Make _____ Model _____ Nozzle Dia. _____ Discharge _____ GPM
 Pressure: Sprinkler _____ Pump Pressure _____

b. Spacing between collection containers (sprinkler spacing _____ (ft)/4) = _____ ft



c. Number of collection containers _____

d. Start of Irrigation event _____

e. End of Irrigation event _____

f. Duration (e-d) _____ hours

g. Operate the system, collect data, and record on the worksheet on page 18.



Wind direction _____
 Wind speed _____

- h. Sum of all catches _____ inches
 i. Average application depth (h/c) _____ inches
 j. Precipitation rate = $\frac{(i)}{(f)}$ = _____ inches/hr
 k. Sum of all deviations from the average catch _____
 l. Average deviation from average application depth _____
 m. Uniformity coefficient


$$U_c = \frac{\text{_____ (i)} - \text{_____ (l)}}{\text{_____ (i)}} \times 100 = \text{_____}$$

Interpret the calibration results.

An application uniformity greater than 75 is excellent for stationary sprinklers.

Application uniformity between 50 to 75 is in the "good" range and is acceptable for wastewater application.

Generally, an application uniformity below 50 is not acceptable for wastewater irrigation. If the computed U_c is less than 50 percent, system adjustments are required. Contact your irrigation dealer or Certified Technical Specialist for assistance.



Calibration Data Sheet for Stationary Sprinkler *(continued)*

Gauge No.	Volume Collected	Overlap Adjustment	Corrected Volume	Deviation from Average*
1	_____	_____	_____	_____
2	_____	_____	_____	_____
3	_____	_____	_____	_____
4	_____	_____	_____	_____
5	_____	_____	_____	_____
6	_____	_____	_____	_____
7	_____	_____	_____	_____
8	_____	_____	_____	_____
9	_____	_____	_____	_____
10	_____	_____	_____	_____
11	_____	_____	_____	_____
12	_____	_____	_____	_____
13	_____	_____	_____	_____
14	_____	_____	_____	_____
15	_____	_____	_____	_____
16	_____	_____	_____	_____
17	_____	_____	_____	_____
18	_____	_____	_____	_____
19	_____	_____	_____	_____
20	_____	_____	_____	_____
21	_____	_____	_____	_____
22	_____	_____	_____	_____
23	_____	_____	_____	_____
24	_____	_____	_____	_____
25	_____	_____	_____	_____
26	_____	_____	_____	_____
27	_____	_____	_____	_____
28	_____	_____	_____	_____
29	_____	_____	_____	_____
30	_____	_____	_____	_____
31	_____	_____	_____	_____
32	_____	_____	_____	_____

*Treat all values as positive.

1	5	9	13	17	21	25	29
2	6	10	14	18	22	26	30
3	7	11	15	19	23	27	31
4	8	12	16	20	24	28	32

NOTE: While in the field, it may be less confusing to record measured values in the grid above, then transfer these values to the data sheet for calculation and interpretation.

Prepared by

R.O. Evans, Biological and Agricultural Engineering Extension Specialist

J.C. Barker, Biological and Agricultural Engineering Extension Specialist

J.T. Smith, Biological and Agricultural Engineering Extension Assistant Specialist

R.E. Sheffield, Biological and Agricultural Engineering Extension Specialist

5,000 copies of this public document were printed at a cost of \$3,084, or \$.62 per copy.

Published by

NORTH CAROLINA COOPERATIVE EXTENSION SERVICE

Distributed in furtherance of the Acts of Congress of May 8 and June 30, 1914. Employment and program opportunities are offered to all people regardless of race, color, national origin, sex, age, or disability. North Carolina State University, North Carolina A&T State University, U.S. Department of Agriculture, and local governments cooperating.